



IN ALL SAILS EXCEPT SPI AND JIB
 PRIMARY REINFORCEMENT MAX. = 600
 AND SECONDARY FREE



SEE ALSO CLASS RULES
 IF NOT OTHERWISE STATED, DIMENSIONS ARE MAX. VALUES

IF-BOOT
SAIL MEASUREMENT RULES